

















9' -10' Prince Snooker Table Assembling Instruction



⑭	Cover plate			10	⑦	Complete bolt		12. 6x255	10
⑬	brass hook			2set	⑥	Large flat head screw		M6x20	18
⑫	screw		5x50	42	⑤	bolt		M8x30	4
⑪	washer		∅35-∅11x3	24	④	SD-011 bracket accessories		30x2	4
⑩	bolt		9. 2x100	24	③	SD-014 long bracket			2
⑨	Snooker Pocket Assembly		4+2	1set	②	SD-013 short bracket			2
⑧	washer		∅35-∅14x3	10	①	screw		4x25	22
Number	Appellation	Description	Measurement (mm)	Pieces	Number	Appellation	Description	Measurement (mm)	Pieces